



## FIBERGLASS BATTEN BETWEEN STUD DETAIL

NOTE: 1) GAP BETWEEN PANELS TO BE LESS THAN 1/8"

3"=1'-0"

- 2) ATTACH BATTEN TO ONE PANEL BEFORE INSTALLATION
- 3) **MUST** PRE-DRILL AND COUNTERSINK HOLES FOR SCREWS

**Bullet Guard**  
Design, Manufacture, Fabrication & Installation of Ballistic Product  
www.bulletguard.com

BALLISTIC FIBERGLASS  
BATTEN BETWEEN STUD  
INSTALLATION DETAIL